

STEP1 **SELECT THE PORT TYPE**

TITANGPS

Determine the type of port that you will be installing the device. Either an OBDII port found in light to medium duty sized vehicles, or JBUS port found in heavy duty vehicles.

STEP 2 DETERMINE THE INSTALLATION METHOD AND CABLE IF REQUIRED

- a) Direct Installation either into the OBDII port or JBUS with a direct connect cable.
- b) Indirect installation into the OBDII port or JBUS with a relocation Y-cable.


STEP 3	STEP 3 CONFIRM LED STATUS		STEP 4	TEST
Green/Blue: Flashing		Online/Valid GPS		To TEST device, call us NOW!

INSTALLATION OBD II Plug directly into Vehicle OBD Port. Ensure that device LED illuminates after plugged in. 00000000 TITANGPS VEHICLE OBD PORT

JBUS INSTALLATION 1. Plug the device into the male OBDII end (1) of direct connect cable. 2. Connect the male JBUS end (2) of direct connect cable to the vehicle JBUS port. 3. Mount the device with correct side facing up.







- 1. Unclip/unscrew vehicle JBUS port from factory mounted position
- 2. Plug the male end of direct connect cable (1) to unmounted vehicle JBUS port
- 3. Mount short (female JBUS) end (2) of direct connect cable to factory mounting position.
- 4. Plug in the device to long male ODBII end (3) of direct connect cable and position under top skin of dash. Ensure correct side is facing up.

